

Water for All: Conserve, Value, Enjoy

1. Positions of water mains and boundary lines of water catchment indicated on plan are approximate.
2. Contractors are to carry out pipe detection work and trial holes dug prior to commencement of earthworks to ascertain the actual alignment of water mains.
3. Steps must be taken to prevent damage to existing water mains. Contractors are liable for damage to PUB water mains.
4. Please call PUB Water And Operations Center (WSOC) at 62824344 should you encounter difficulties in locating the water mains. WSOC is to be informed immediately, should you encounter a leak on our water mains in the course of your work.


Type Of Water Mains

PUB Water Mains	Dia
NEWater Mains	NW – Dia
Industrial Water Mains	IW – Dia
Raw Water Mains	RW – Dia

Legend:

Existing Water Mains	
Proposed Water Mains	
Water Mains Under Construction	
Abandoned Water Mains	
Control Valve	
Control Valve – Closed	
Non – Return Valve	
Air Valve	
Washout	
Access Manhole	
Flow Meter	
Bulk Meter	
Reducer	
Blank Flange	
Double Pillar Hydrant	
Ground Pillar Hydrant	
Triple Pillar Hydrant	
PUB Installation	
Water Catchment Boundary	
Drain Line	

**WATER SUPPLY (NETWORK) DEPARTMENT
NETWORK DATA AND ASSET MANAGEMENT**



SCALE 1: 750

THE APPROXIMATE PROPOSED SITE MARKED IN **YELLOW** IS PARTIALLY WITHIN PANDAN WATER CATCHMENT AREA

DONE BY: KARIM J

DATE: 20-05-08